BELKIN

Chef Stand + Wand for Tablets

Use Your Tablet While You Cook

Part # F5L099cw

Use Your Tablet While You Cook

Designed with Home Chefs in Mind
Made especially for use in the kitchen, the Chef Stand + Wand gives you the freedom to interact with your tablet while you cook—without worrying about touching your device with messy hands. The case-compatible stand has a non-slip rubber base and two different angles that are ideal for countertop use.

Like Magic
The wand allows you to follow recipes and browse the Internet without ever laying a finger on your screen. It comes with its own storage stand and is easy to grab while you're busy handling food and other kitchen equipment. The magnetic tip works with any touchscreen, and can be used to wake up an iPad 2.All components can be washed by hand using warm, soapy water.

Features

- Kitchen-safe and made for use with messy hands
- Stand has a non-slip rubber base and dual angles for easy viewing on a kitchen countertop
- Wand is easy to grip and has a magnetic tip that can wake up an iPad 2
- Includes stand, wand, wand holder
- Case-compatible
- 3-Year warranty

© 2010 Belkin International, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.